

SUNSYNK Lithium Battery Compatibility List

Brand	Model	48V Storage Inverter	RS485 / CAN	Inverter Setup	Note
PYLONTECH	US2000	●	Both	0	
PYLONTECH	US3000	●	Both	0	
DYNESS	B4850	●	CAN	0	
DYNESS	B48100	●	CAN	0	PINS 6&7 must be shorted on the Inverter side
DYNESS	Powerbox 9.6	●	CAN	0	
SolarMD	SS4037	●	CAN	0	To be used with V2 Logger http://solarmd.co.za/inverter-compatibility-solarmd/sunsynk-and-solar-md/
SolarMD	SS4074	●	CAN	0	To be used with V2 Logger http://solarmd.co.za/inverter-compatibility-solarmd/sunsynk-and-solar-md/
SolarMD	SS202	●	CAN	0	To be used with V2 Logger http://solarmd.co.za/inverter-compatibility-solarmd/sunsynk-and-solar-md/
Freedomwon	Freedom Lite Commercial52V and HV Models	●	CAN	0	www.freedomwon.co.za/storage/2019/09/freedom-lite-commercial-installation-manual-rev-2-september-2019.pdf
REVOV	1st and 2nd Life	●	RS485		PINS 1&2 must be Swopped at Battery side.
NARADA	48100		No		Volatage Base Charge settings must be used.
SHOTO			No		Volatage Base Charge settings must be used.
HUBBLE			No		Volatage Base Charge settings must be used.